



HELP MAXIMIZE DISHMACHINE  
PERFORMANCE

## Keystone Lime-A-Way® Lime Scale Remover

- ▲ Helps eliminate lime scale deposits on contact
- ▲ Cleans dishmachine rinse arms, coils and jets
- ▲ Use on dishmachines, steam tables, stainless steel, tile, porcelain and other surfaces

Keep your warewashing  
system free of lime scale  
build-up to help reduce  
energy costs.



**Keystone Lime-A-Way Lime Scale Remover** removes hard water deposits and lime scale from dishmachines and other surfaces.

## DIRECTIONS FOR USE:

### Dishmachines:

1. Fill tank to 2-3 inches (5-8 cm) below overflow.
2. Turn on tank heaters.
3. Add entire contents of product.
4. Run machine until lime scale disappears.
5. Apply full strength where spray does not reach. Scrape off heavy lime build-up.
6. Drain tank. Refill with potable water. Run machine five minutes and drain.
7. Delime as necessary to prevent recurrence of lime scale.

For other kitchen appliance directions, see the product label for instructions.

Keystone combines the foodservice knowledge of Sysco, with the cleaning and sanitization expertise of Ecolab. Our experienced and dedicated sales teams provide you personalized support to help you run a clean and safe operation.



## WAREWASHING SOLUTIONS

PRODUCT	PICK CODE	SUPC CODE	PACK SIZE
Keystone Lime-A-Way Lime Scale Remover	6100053	7670021	2-1 gal